



For Windows

- How to download Data Transfer Software


1. Save the compressed file of
758DataTransferSoftware2_WIN_E.zip” on the
desktop or selected folder.




2. Select the compressed file and right-click to select
“Decompress”(If any compress/decompress software
is installed) or “Extract All” (If any
compress/decompress software is NOT installed in
Windows XP)



3. Double-click the folder of "setup"




4. Start up the Setup Wizard, and follow the same procedure of installation in Software Guide (P19).




- **How to download USB Driver for L-758series**

<Note> If you have ever downloaded “Data Transfer Software” from CD-ROM which is included in the packaging when you purchased once before, USB driver had been already installed, and no need to install again.


1. Save the compressed file of “DriverDataTransferSoftware2_WIN4.40” on the desktop or selected folder.




2. Select the compressed file and right-click to select “Decompress”(If any compress/decompress software is installed) or “Extract All” (If any compress/decompress software is NOT installed in Windows XP)



3. Double-click the folder of "L758DriverInstaller"



4. Start up the installer, and follow the same procedure of installation in Software Guide (Page 18)



For Macintosh

- How to download the Data Transfer Software and USB driver for L-758 series.

*You can install the both application and USB driver at the same time with Macintosh version.

1. Save a ZIP file on desktop or a specified place.



2. Double click the compressed folder “Data Transfer Software.pkg”, and “DataTransferSoftware(2.0).mpkg” is made.

3. Double click “DataTransferSoftware(2.0)” to make the installer stand up, and the following procedure is the same as the installation method in software guide (P12).

